
# **Controlling Chemical Bath Temperature**

# Set up

```
% Scenario: we need a temperature controlled bath for a chemistry
% experiment. The temperature of the bath is assumed to be constant
% throughout by use of a magnetic stirrer. There is a constant flow of
% water into the bath through a long pipe, so there is a convective time
% delay of 12 seconds. The baseline temperature for the bath is 35C. The
% maximum and minimum possible temperatures for the bath is 50c and 10c
% respectively. The goal of this exercise is to determine the K value for
% the proportional controller in order to minimise settling time.
d=12;
a0=0.02; % just a constant in the governing equation
ys= pade(d,2); % second order pade delay approximation
us= tf(1,[1/a0 1] ); % plant transfer function
gs= ys(1,1)*us; % plant transfer function accounting delay
figure(1), rlocus(gs), title('Root Locus of Plant');
```

# 3 ×10<sup>---</sup> 2 -




**Root Locus of Plant** 

Tmin= 10;Tmax=50;Taim=45;Taiml= 45-0.5;Taimu=45-0.5;Tstart=35;
% From the root locus of the plant, we can see that the system has one
% negative real pole.

dsk1= 1; % proportional controller
oltf\_k= dsk1\*gs; % open loop transfer function of plant and controller
cltf\_k= feedback(oltf\_k,1); % closed loop transfer function with negative feedback
ssgain\_k= dcgain(cltf\_k) % steady state gain so that the loop prefactor can be
determined

ssgain\_k = 0.5000

stepexp\_k= Tstart+ (1/ssgain\_k)\*Tmin\*cltf\_k; % closed loop transfer function
accounting for loop prefactor, baseline temperature (35c) and step temperature (10c)
figure(2),step(stepexp\_k), title('CLSR with Proportional Controller K=1');



### stepinfo(cltf\_k)


ans = struct with fields:
 RiseTime: 54.9252
TransientTime: 97.8019
 SettlingTime: 97.8019
 SettlingMin: 0.4523
 SettlingMax: 0.4997
 Overshoot: 0
 Undershoot: 0
 Peak: 0.4997
 PeakTime: 183.0555

% A large negative real root should mean rapid settling time. The control strategy is to increase K by a factor of 10.

## **Proportional Controller K=10**

```
dsk10= 10;
oltf_k10= dsk10*gs;
cltf_k10= feedback(oltf_k10,1);
ssgain_k10= dcgain(cltf_k10)
ssgain_k10 =
0.9091
stepexp_k10= Tstart+ (1/ssgain_k10)*Tmin*cltf_k10;
figure(3),step(stepexp_k10), title('CLSR with Proportional Controller K=10');
```

# **CLSR with Proportional Controller K=10**




### stepinfo(cltf\_k10)


```
ans = struct with fields:
        RiseTime: 9.9864
   TransientTime: 17.7822
    SettlingTime: 17.7822
     SettlingMin: 0.8223
     SettlingMax: 0.9085
       Overshoot: 0
       Undershoot: 0
            Peak: 0.9085
         PeakTime: 33.2828
```

```
dsk100= 100;
```

```
oltf k100= dsk100*gs;
cltf_k100= feedback(oltf_k100,1);
ssgain_k100= dcgain(cltf_k100)
ssgain_k100 =
0.9901
```



# **CLSR with Proportional Controller K=100**



### stepinfo(cltf\_k100)


```
ans = struct with fields:
        RiseTime: 1.0876
   TransientTime: 1.9367
    SettlingTime: 1.9367
      SettlingMin: 0.8955
      SettlingMax: 0.9894
        Overshoot: 0
      Undershoot: 0
             Peak: 0.9894
         PeakTime: 3.6249
```

```
dsk1000= 1000;
oltf_k1000= dsk1000*gs;
cltf_k1000= feedback(oltf_k1000,1);
ssgain_k1000= dcgain(cltf_k1000)
```

```
ssgain_k1000 = 0.9990
```

```
stepexp_k1000= Tstart+ (1/ssgain_k1000)*Tmin*cltf_k1000;
figure(5),step(stepexp_k1000), title('CLSR with Proportional Controller K=1000');
```





### stepinfo(cltf\_k1000)


```
ans = struct with fields:
    RiseTime: 0.1097
TransientTime: 0.1954
SettlingTime: 0.1954
SettlingMin: 0.9036
SettlingMax: 0.9983
    Overshoot: 0
Undershoot: 0
Peak: 0.9983
PeakTime: 0.3657
```

```
dsk10000= 10000;
oltf_k10000= dsk10000*gs;
cltf_k10000= feedback(oltf_k10000,1);
ssgain_k10000= dcgain(cltf_k10000)

ssgain_k10000 =
0.9999

stepexp_k10000= Tstart+ (1/ssgain_k10000)*Tmin*cltf_k10000;
```





### stepinfo(cltf\_k10000)

ans = struct with fields:
 RiseTime: 0.0110
TransientTime: 0.0196
SettlingTime: 0.0196
SettlingMin: 0.9044
SettlingMax: 0.9992
Overshoot: 0
Undershoot: 0
Peak: 0.9992
PeakTime: 0.0366

% From this exercise, it stands to reason that as K increases % exponentially, the settling time will decrease exponentially.